



Sea-Bird Electronics, Inc.
1808 136th Place NE
Bellevue, WA 98005
USA

Phone: (425) 643-9866
Fax: (425) 643-9954
E-mail: seabird@seabird.com
Web: www.seabird.com

APPLICATION NOTE 18-3

JULY 2001

SBE 18 pH Sensor Hookup Instructions

To minimize chances of corrosion, avoid metal-to-metal contact of the aluminum instrument case with the mounting device -- e.g., use insulating tape or heat-shrink tubing over stainless steel hose clamps if they are used to mount the instrument.

The instrument case is filled with dry nitrogen. If it is necessary to open the case at any time, refill the case with nitrogen to prevent possible condensation at low temperatures.

The pin configuration on the instrument case is:

