



Sea-Bird Electronics, Inc.  
1808 136th Place NE  
Bellevue, WA 98005  
USA

Phone: (425) 643-9866  
Fax: (425) 643-9954  
E-mail: [seabird@seabird.com](mailto:seabird@seabird.com)  
Web: [www.seabird.com](http://www.seabird.com)

## APPLICATION NOTE NO. 39

Revised June 2006

### CALCULATING CALIBRATION COEFFICIENTS FOR THE CHELSEA AQUATRACKA FLUOROMETER

The Chelsea Aquatracka fluorometer measures Chlorophyll-*a* concentrations in the approximate range of 0.01 µg/l to 100 µg/l with a logarithmic output of nominally 0 to +4 volts.

Select Fluorometer, Chelsea Aqua 3 as a voltage sensor when setting up the configuration (.con) file in Sea-Bird software. The software calculates:

$$\text{concentration } [\mu\text{g/l}] = \text{slope} * (10^{\text{V}/\text{sf}} - 10^{\text{VB}}) / (10^{\text{V}_1} - 10^{\text{Vacetone}}) + \text{offset}$$

where	V	=	fluorometer output voltage <i>in-situ</i>
	slope	=	nominally 1.0; user may adjust to fit field data <sup>1</sup>
	sf	=	scale factor (1.0 except as follows; 2.0 for versions of the SBE 9 having input amplifiers with a gain of 2)
	VB	=	electrical zero (from Chelsea calibration sheet) <sup>2</sup>
	V1	=	fluorometer output voltage at 1 µg/l (from Chelsea calibration sheet)
	Vacetone	=	fluorometer output voltage at zero chlorophyll (from Chelsea calibration sheet) <sup>3</sup>
	offset	=	nominally 0.0; user may adjust to fit field data <sup>1</sup>

**Note:** The CTD configuration (.con) file is edited using the Configure menu (in SEASAVE or SBE Data Processing in our SEASOFT-Win32 suite of programs) or the Configure Inputs menu in SEASAVE V7.

<sup>1</sup> Users may wish to *adjust* the fluorometer readings to conform to measured concentrations. For example, from two *in-situ* samples and with the slope and offset set to 1.0 and 0.0 respectively, a user might observe that the software indicated a concentration of 0.390 when the concentration determined from a water sample was 0.450, and 0.028 when the concentration determined from a water sample was 0.020. A linear regression to these data would give *slope* = 1.188 and *offset* = -0.013. The introduction of these *fit* coefficients in the instrument configuration (.con) file would then correct the indicated concentrations. In general, VB, V1, and Vacetone as listed on the original Chelsea factory calibration sheet can be used throughout the life of the instrument, with subsequent calibrations used to adjust slope and offset alone.

<sup>2</sup> Chelsea defines VB as ideally being equal to the *clean water* response of the fluorometer. They suggest substituting the *electrical zero* (also referred to as *VBdefault*) when the *clean water* reading is unknown and hard to obtain - as is usually the case.

<sup>3</sup> Vacetone is determined with acetone in a special calibration cell (available from Chelsea Instruments), **NOT WITH THE FLUOROMETER IMMERSED IN ACETONE. Exposing the fluorometer lenses to acetone will PERMANENTLY DAMAGE THE FLUOROMETER LENSES.**